



USER MANUAL

DIGITAL ANEMOMETER SYSTEM

AM-100

NOTICE TO USERS

- Thanks for your purchasing this product AM-100 digital anemometer system.
- Please read this manual carefully to ensure proper use before installation and operation of the AM-100.
- NSR will assume no responsibility for the damage caused by improper use or modification of the product or claims of loss of profit by a third party.
- NSR reserves the right on continuous improvement of products both in software and hardware without any prior notice.
- The copyright of this manual is owned by the manufacturer, NEW SUNRISE CO., LTD (NSR). Prior written permission is required for copying or reproducing the manual or part of the manual.
- Please keep the manual for your future reference.

MODIFY RECORD

No.	Modify by	Date	Paragraph	Version	Reason
1	Q/A	2010/07/09		01	First edition
2	Q/A	2016/03/04	2, 3, 5.1, 5.5	02	a. System diagram revised from DC24V to AC220V. b. Photos increased
3	Q/A	2022/11/02	all	03	General modification
4	Q/A	2024/02/29	3, Appendix	04	Some modification

TABLE OF CONTENTS

1. GENERAL	1
2. SYSTEM CONFIGURATION.....	2
3. TECHNICAL SPECIFICATIONS.....	3
4. OPERATION	4
4.1 DIRECTION INDICATORS	4
4.2 DIGIT WINDOW	4
4.3 CONTROL BUTTONS	4
5. INSTALLATION	5
5.1 INSTALLATION OF TRANSMITTER	5
5.2 INSTALLATION OF DISPLAY UNIT	5
5.3 INSTALLATION OF REMOTE BUTTON	5
5.4 INSTALLATION OF JUNCTION BOX.....	5
5.5 CABLE CONNECTION BETWEEN UNITS.....	6
APPENDIX INSTALLATION DRAWINGS.....	8

1. GENERAL

AM-100 digital anemometer system is specially designed for marine use. The transmitter installed on radar mast is made of special nylon to protect from strong wind and salty air at sea. With 72 LED indicators, both relative and true wind direction can be clearly displayed. For large vessels, up to four display units can be installed on bridge and other locations on board. For easy operation, a remote button can be installed at operator's to control the display unit.


The digital anemometer can provide six ports of RS-422 wind data to various externals, including (S)VDR, INS, etc.

2. SYSTEM CONFIGURATION

The system consists of five main parts:

- **AM-100T** Anemometer Transmitter
- **AM-100D** Display Unit
- **AM-100R** Remote Button (Optional)
- **AM-100J** Junction Box
- **AM-100TJ** Watertight box for Transmitter

Normally one Display Unit is connected to Junction Box, but four ports are available for maximum 4 sets of Display Units to be connected, especially for some large vessels. Each Display Unit can be connected with one Remote Button for easy operation.



NOTE: ----- Optional or Yard Supplied

Fig 2.1 Block Diagram of Anemometer System

3. TECHNICAL SPECIFICATIONS

NO	ITEM	Wind Speed	Wind Direction
1	Wind Range	0~60 m/s	0~360°
2	Accuracy	$\pm(0.5+V\times 5\%)$ m/s	$\pm 5^\circ$
3	Display Capacity	Up to 4 Display Units can be connected	
4	Input Interface (see note)	Heading data input (Compass): NMEA0183, RS422, 4800bps Speed data input (Speed Log): NMEA0183, RS422, 4800bps	
5	Output Interface	Port Number: RS422 6 ports Output Format: NMEA0183 Baud Rate: 4800bps Output Sentence: \$WIMWV,180.00,R,30.5,M,A*2D	
6	Operating Environment	Indoor 0~+40°C Outdoor -30°C~+70°C	
7	Power Supply	AC110V/220V	
8	Power Consumption	Max 12W	
9	Weight	Transmitter (AM-100T) 3kg Display Unit (AM-100D) 0.2kg Remote Button (AM-100R) 0.1kg Junction Box (AM-100J) 2.7kg Watertight Box (AM-100TJ) 0.2kg	

NOTE: Input sentences are for calculating true wind.

One of the conditions below should be satisfied:


- A. Compass HDT + Speed Log VBW
- B. Compass HDT + GNSS RMC
- C. GNSS RMC

4. OPERATION

4.1 Direction Indicators

There are totally 72 LED indicators. Each LED represents 5 degrees in wind direction. Among 72 LEDs, 12 LEDs are in **yellow**, representing 0, 30, 60, 90, 120, 150, 180 degree, and the right LEDs are in **green** and left LEDs are in **red**.

Depending the direction in which the wind comes from, all the LEDs in the sector from 0 degree to that direction will light on.

The brightness of the LEDs can be adjusted by pressing the  button.

4.2 Digit Window

In the Digit Window, three digits can be displayed.


The displayed contents can be Heading degree or wind speed or ship speed. The change among

three values is controlled by  button.


The default value displayed is wind direction. If no button is pressed in 5 minutes, wind speed will be displayed no matter what the current status is.


4.3 Control Buttons


There are four control buttons, which are described as below.



Continuously press the button to select the following functions:

-  ① **k/n** indicator on. Either wind speed or ship speed is displayed in k/n.
 ② **m/s** indicator on. Only wind speed can be displayed in m/s.
 ③ **HEADING** indicator on. Heading data is displayed in window.
 ④ **SHIP SPEED** indicator on. Ship speed is displayed in window.

 T/R
 Change between True wind and Relative wind. Both direction and speed will be changed accordingly.

 RESET
 Press “RESET” to reset the display unit or switch off it. When the display unit is switched off, LED on the button will light on.

5. INSTALLATION

5.1 Installation of Transmitter

The Transmitter should be installed in clear space to avoid any obstacle of wind.

There is an installation base and installation plate supplied together with the Transmitter. The steel base should be welded directly or through a support pole on the radar mast. There are five long holes on the round base. The center of one of five holes should be pointed to ship bow. Keep the base horizontal while welding. The installation plate is to protect the Transmitter base from cracking while fastened.

There are five round holes on the Transmitter base. Fix the transmitter on the mount base with five M10X45 bolts. The long-holes on mount base are used to for the transmitter to adjust until the “N” mark on Transmitter base points to bow direction.

The transmitter should be grounded through the small junction box with a grounding cable.

5.2 Installation of Display Unit

The Display Unit is flush mount-type. Make a cutting area as attached drawing. Usually the Display Unit can be installed on bridge console or up the bridge.

5.3 Installation of Remote Button

Same as the Display Unit, the Remote Button is also flush mount-type. Make a cutting area as attached drawing.

Remote Button is optional part. When the Display Unit is installed up the bridge, in which case, panel operation is impossible, a Remote Button is necessary to operate the Display Unit.

5.4 Installation of Junction Box

Junction Box can be mounted on table or wall. Enough space should be kept for cabling.

5.5 Cable Connection between Units

- **Connect Transmitter to Junction Box**

A watertight box is used to connect Transmitter and Junction Box.




Fig 5.1 Connection between Transmitter and Junction Box

Rubber cable is recommended for outdoor environments. After cable connecting, it is suggested to use rubber tape to wrap the cable gland for water-tight treatment.

- **Connect Display Units to Junction Box**

A 4-wire cable is supplied in length of 10m for connection between AM-100D Display Unit and AM-100J Junction Box. Interface between the units is also RS422.

Max four Display Units can also be connected to Junction Box. Each Display Unit can operate independently.




Fig 5.2 Connection between Display Unit and Junction Box

- **Connect Remote Button to Display Unit**




Fig 5.3 Connection between Remote Button and Display Unit

A 6-wire cable is supplied in length of 10m for connection between AM-100D and AM-100R. The AM-100R Remote Button is an optional part of the system. All the panel operating function can be realized through AM-100R Remote Button.

- **Connect with Compass and Speed Logger**

Heading data and Ship Speed data should be input into AM-100J Junction Box in order to calculate the true wind's speed and direction. Refer to manuals of Speed Logger and Compass for connections. The input data should be in NMEA0183 format/RS422, at baud rate of 4800bps.




- **Connect with (S)VDR and other externals**

Totally there are six output ports of wind data. The data format is NMEA0183 at baud rate of 4800bps. The data sentence is as follows:
 \$WIMWV,180.00,R,30.5,M,A*2D

APPENDIX INSTALLATION DRAWINGS


Drawing No.	Description
AM100-ID-001	AM-100 ANEMOMETER SYSTEM DIAGRAM
AM100-ID-002	AM-100 ANEMOMETER SYSTEM WIRING DIAGRAM
AM100-ID-003	AM-100T ANEMOMETER TRANSMITTER SIZE DRAWING
AM100-ID-004	AM-100TJ WATERTIGHT BOX SIZE DRAWING
AM100-ID-005	AM-100J JUNCTION BOX SIZE DRAWING
AM100-ID-006	AM-100D DISPLAY UNIT SIZE DRAWING
AM100-ID-007	AM-100R REMOTE BUTTON SIZE DRAWING

NO.	DATE	REVISION & DESCRIPTION	DESIGN	DATE	REVISION	DESCRIPTION




APPLICATION: AM-100 ANEMOMETER SYSTEM WIRING DIAGRAM										
DATE	APP'D	CHK'D	ENT'D	DESIGN	SCALE	UNIT	INCH	MM	SHEET NO.	TOTAL SHEETS
DRAWING NO.: AM100-ID-002										

--- YARD SUPPLIED ---



INSTRUCTIONS


1. The plate is installed upon the transmitter base to be protected from cracking when hardly fastened.
2. Two half-circle plates make one complete circle.
3. Material: Steel A3,Zn coating.



INSTALLATION PLATE

INSTRUCTIONS

1. The Base is fixed on mast directly or with a support pole by welding.
2. The center of one of five long holes points to bow while the base is fixed.
3. While welding, the base should be kept horizontally.
4. Material: Steel A3,Zn coating.




INSTALLATION BASE

Materials:


1. Wing part : PC
2. Lower part : Nylon with 30% glass
3. Installation plate/base : Steel A3,Zn coating

NO.	DATE	REVISION & DESCRIPTION	REVISED	DESIGN

APPLICATION										AM-100T ANEMOMETER TRANSMITTER SIZE DRAWING													
DATE	APP'D	CHK'D	ENT'D	DES'G	DRW'G	INSTR.	SCALE	UNIT	PROJ.	SHEET	TOTAL	DATE	SCALE	UNIT	PROJ.	SHEET	TOTAL	DATE	SCALE	UNIT	PROJ.	SHEET	TOTAL
NSR NEW SUNRISE CO., LTD.																							
AM100-ID-003																							



FRONT VIEW




SIDE VIEW

NO.	DATE	REVISION & DESCRIPTION	REVISED BY	DESIGN

APPLICATION		AM-100TJ WATERTIGHT BOX SIZE DRAWING	
DATE	SCALE	DATE	SCALE
APPROVAL	DATE	APPROVAL	DATE
DESIGN	DATE	DESIGN	DATE
DRAWING	DATE	DRAWING	DATE
INSTR.	DATE	INSTR.	DATE

NSR NEW SUNRISE CO., LTD.




NO.	DATE	REVISION & DESCRIPTION	DESIGNED
1			DATE
			SYMBOL



APPLICATION		AM-100J JUNCTION BOX SIZE DRAWING	
DATE	ITER	SCALE	SHEET NO.
APPROVAL	CHK	DATE	TOTAL SHEETS
DRAWING	NO.	DATE	NO.
NO.	NO.	NO.	NO.
AM100-ID-005			
NSR NEW SUNRISE CO., LTD.			

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80 81 82 83 84 85 86 87 88 89 90 91 92 93 94 95 96 97 98 99 100


NO.	DATE	REVISION & DESCRIPTION	DESIGNER	DATE




TOP VIEW




FRONT VIEW



SIDE VIEW



REAR VIEW



YARD AREA CUTTING SIZE

APPLICATION		AM-100D DISPLAY UNIT SIZE DRAWING	
DATE	ITER	DATE	ITER
APPROVAL	DATE	APPROVAL	DATE
CHECKED	DATE	CHECKED	DATE
DRAWING	DATE	DRAWING	DATE
NO. IN SET	NO. OF SETS	NO. IN SET	NO. OF SETS
NSR NEW SUNRISE CO., LTD.		NSR NEW SUNRISE CO., LTD.	
AM100-ID-006		AM100-ID-006	

A B C D E F G H I J K L M N O P Q R S T U V W X Y Z

Copyright by NEW SUNRISE CO., LTD. (NSR)

www.nsrmarine.com

info@nsrmarine.com

February, 2024